




SLIM RADIO CONTROLLED PROJECTION CLOCK WITH INDOOR THERMOMETER


LAVA

INSTRUCTION MANUAL




40

KSPO: 0737-12(OST)
IROX PCR156 MANUAL 4(ENGLISH)
SIZE: W75 X H85(mm)
BY Lai H Z 21/09/12



41

To install the AC-DC adapter for Continue Projection:-



Installation:
Use 2 x "AAA", 1.5V batteries and AC-DC adapter (included).

Important:
Please make sure your household voltage matched with the voltage supported by the adapter, or it will damage your clock and adapter.

42

INDICATOR	STANDING FOR	INDICATOR	STANDING FOR
RADIO SIGNAL	RADIO SIGNAL	W	RADIO SIGNAL WEAKLY
D	DATE	Z	REPEAT ALARM INDICATION
FOREIGN TIME INDICATION	FOREIGN TIME INDICATION	M	MONTH
PM	PM (12 HR DISPLAY ONLY)	S	SUMMER TIME INDICATION
AM	AM (12 HR DISPLAY ONLY)	°C	DEGREE CELSIUS
ALARM 1	ALARM 1	°F	DEGREE FAHRENHEIT
ALARM 2	ALARM 2	DT	DUAL TIME

* After the batteries are installed, the LCD will turn on and beep for 2 seconds. The clock will automatically search the radio signal. It takes about 3-5 minutes to finish this process.

* If the radio signal is received, the date & time will be set automatically with radio control signal icon [RADIO] turns on.

* If the clock fails to receive the time signal, it will be in Time/Temperature display with the [RADIO] icon turns off. Then user can set the time manually.

* Radio-controlled signal will be scheduled to receive every hour.

43

Selecting Temperature/Alarm 1/Alarm 2/Dual time Display

*Press MODE will display the ALARM 1 time:




*Press MODE again will display the Alarm 2 time:



*Press MODE again will display the Dual Time:



*Press MODE again will display the Temperature:



44

Manual Time Setting

The system date and time can be set by pressing **MODE** for 3 seconds in Time/Temperature display with the [⌚] icon turn off.

Setting the Time

*Press **MODE** again: the year digits are blinking and can be set by pressing ▲ or ▼ key.



*Press **MODE** again: the month digits are blinking and can be set by pressing ▲ or ▼ key.



*Press **MODE** again: the date digits is blinking and can be set by pressing ▲ or ▼ key.



*Press **MODE**: the hour digits are blinking and can be set by pressing ▲ or ▼ key.



*Press **MODE** again: the minute digits are blinking and can be set by pressing ▲ or ▼ key.



45

*Press **MODE** one last time: the normal time display appears.

Select 12 hour or 24 hour display format

*Press ▲ will toggle the display format between 12 hour and 24 hour.

N.B.:1. If no key is pressed within 30 seconds, it will exit the Manual

Time Setting Mode and go back to Time / Temperature

Display without the data update.

2. During any setting mode, press and hold ▲ or ▼ key for

2 seconds for fast setting.

3. View week of the year, press ▼ key will toggle between the day

of week and the calendar week.

Calendar

To change the weekday display from one language to another language, press ▼ key for 3 seconds - the display will show the current language (GER for German display, ENG for English display).

① "EN" for English → ② "DE" for German → ③ "FR" for French →

④ "IT" for Italian → ⑤ "ES" for Spanish.

Press & Hold ▼ key for 2 seconds will toggle to the other languages.

Setting the Alarm time

ALARM 1 setting

-In the ALARM 1 Display,

*Press **MODE** for about 3 seconds: the hour digits are blinking and can

set by pressing ▲ or ▼ key.

*Press **MODE** again: the minute digits are blinking and can be set by

pressing ▲ or ▼ key.

46

*Press **MODE** again, the Alarm time is set and [⌚] icon will turn on.

ALARM 2 setting

-In the ALARM2 Display,

*Press **MODE** for about 3 seconds: the hour digits are blinking and can

set by pressing ▲ or ▼ key.

*Press **MODE**again: the minute digits are blinking and can be set by

pressing ▲ or ▼ key.

*Press **MODE**again, the Alarm time is set and [⌚] icon will turn on.

Enable Alarm 1/Alarm 2:

*Press **ALARM** will enable ALARM 1 with [⌚] icon turns on.



* Press **ALARM** again will enable ALARM 2 with [⌚] icon turns on.



* Press **ALARM** again will enable both ALARM 1 and ALARM 2 with [⌚] and [⌚] icons to turn on.



* Press **ALARM** again will disable both ALARM 1 and ALARM 2 with [⌚] and [⌚] icons to turn off.



47

Activating the Alarm

When the ALARM 1/ALARM 2 is ringing, the relative alarm icon [⌚] / [⌚] will be flashing.

* Press **ALARM** key to turn the alarm off.

* Press [SNOOZE / LIGHT] - alarm stops and the backlight will turn on for 5 seconds with deleted, the repeat alarm indicator (⌚) flashing. The alarm sounds again after 4 minutes.

* If the alarm is not turned off, it will stop automatically after 4 minutes.

Foreign Time Display & setting

* Press and hold ▲ key for 3 seconds, the icon "⌚" will turn on.

* Press and hold **MODE** for 3 seconds in Foreign Time / Temperature display.

The Foreign time can be set as described above by pressing ▲ or ▼ key.

* Press **MODE** key again to confirm the setting of foreign time.

* Press and hold ▲ key for 3 seconds to choose between local and foreign time display.



Setting the Dual Time

* The dual time can be set by pressing **MODE** for 3 seconds in Dual Time Display. The hour will flash for input.

* Press **MODE**: the hour of dual time display digits are blinking and can be set by pressing ▲ or ▼ key.

48

* Press **MODE** again: the minute of dual time display digits are blinking and can be set by pressing ▲ or ▼ key.



* Press **MODE** again to confirm the setting.

Light ON / OFF

* Press top button [SNOOZE / LIGHT] key - light will come on and turn off automatically after 5 seconds.



Projection Light and its adjustment

* Press button [SNOOZE / LIGHT] - Projection light will come on and turn off automatically after 5 seconds.



* When insert adapter and turn on the "Continue - Projection" button, projection light will turn on continuously until the button is switched off or the AC adapter is pulled off.

* Press [FLIP] key to rotate the projection image in 180° orientation clock wise.

IMPORTANT NOTICE:

The projection is only visible in dark rooms. It can not be made visible at daylight. The LED of the projection has a limited lifetime and can not be replaced. Should you make use of the permanent projection, we strongly recommend to switch it off during daytime or at times not needed. By doing this, you will have a much longer benefit of all the functions of the clock - including the projection!

Temperature function

Press [°C/F/WAVE] to select the temperature display between Celsius or Fahrenheit.



Receiving the DCF77 radio clock signal

The projection clock will automatically receive the DCF77 radio clock signal every hour.

Besides, you can force the clock to receive the signal by pressing [WAVE] for 3 seconds, It will take 3-5 minutes to receive the radio signal. If the time signal is received, the [⌚] icon will be on otherwise it will be off.

49

50

Specifications

Indoor Temperature measurement	: 0°C to +50.0°C (32.0°F to 122.0°F)
Proposed operating range	: 0.1°C (0.2°F)
Temperature resolution	: approx. 1 minute
Temperature sensing cycle	: use 2 pcs UM-4 “AAA” 1.5V batteries
Power	: 150g
Weight	: 153 x 103 x 12mm
Dimension	



Attention! Please dispose of used batteries in
an ecologically safe manner.